



Motion Pro, Inc.  
867 American Street  
San Carlos, CA 94070  
Tel 650.594.9600 Fax 650.594.9610  
www.motionpro.com

## INSTRUCTIONS

### ATV SWITCH MOUNT KIT PART#11-0026

This switch mount kit is used in conjunction with Motion Pro Twist Throttle Conversion Kits 01-0397 and 01-0398. This will relocate the 2WD & 4WD switch to the handle bars.



1. Slide the rings on the throttle side of the bars
2. Put the back plate on the exposed side of the switch.
3. Align the switch and place holes to the holes in the rings.
4. Use the screws to fasten the assemble together.
5. Put your switch in desired position and tighten the inset screws to secure.

**Note: Must be installed prior to throttle installation.**

I11-0026

102010



Motion Pro, Inc.  
867 American Street  
San Carlos, CA 94070  
Tel 650.594.9600 Fax 650.594.9610  
www.motionpro.com

## INSTRUCTIONS

### ATV SWITCH MOUNT KIT PART#11-0026

This switch mount kit is used in conjunction with Motion Pro Twist Throttle Conversion Kits 01-0397 and 01-0398. This will relocate the 2WD & 4WD switch to the handle bars.



1. Slide the rings on the throttle side of the bars
2. Put the back plate on the exposed side of the switch.
3. Align the switch and place holes to the holes in the rings.
4. Use the screws to fasten the assemble together.
5. Put your switch in desired position and tighten the inset screws to secure.

**Note: Must be installed prior to throttle installation.**

I11-0026

102010



Motion Pro, Inc.  
867 American Street  
San Carlos, CA 94070  
Tel 650.594.9600 Fax 650.594.9610  
www.motionpro.com

## INSTRUCTIONS

### ATV SWITCH MOUNT KIT PART#11-0026

This switch mount kit is used in conjunction with Motion Pro Twist Throttle Conversion Kits 01-0397 and 01-0398. This will relocate the 2WD & 4WD switch to the handle bars.



1. Slide the rings on the throttle side of the bars
2. Put the back plate on the exposed side of the switch.
3. Align the switch and place holes to the holes in the rings.
4. Use the screws to fasten the assemble together.
5. Put your switch in desired position and tighten the inset screws to secure.

**Note: Must be installed prior to throttle installation.**

I11-0026

102010



Motion Pro, Inc.  
867 American Street  
San Carlos, CA 94070  
Tel 650.594.9600 Fax 650.594.9610  
www.motionpro.com

## INSTRUCTIONS

### ATV SWITCH MOUNT KIT PART#11-0026

This switch mount kit is used in conjunction with Motion Pro Twist Throttle Conversion Kits 01-0397 and 01-0398. This will relocate the 2WD & 4WD switch to the handle bars.



1. Slide the rings on the throttle side of the bars
2. Put the back plate on the exposed side of the switch.
3. Align the switch and place holes to the holes in the rings.
4. Use the screws to fasten the assemble together.
5. Put your switch in desired position and tighten the inset screws to secure.

**Note: Must be installed prior to throttle installation.**

I11-0026

102010